

Care & Maintenance Guidelines for KENTEER® Series Car Wrapping Vinyl:

1. Do not touch after construction, as there may be subsequent generation of bubbles or water bubbles, which is a normal phenomenon and may disappear naturally after 10-20 days. You can also conduct self-inspection and processing
2. Do not flush or wash the car for 7 days after applying the film.
3. When washing the car, avoid using a high-pressure water gun to spray and rinse the joint between the film and the car paint.
4. Do not use brushes, abrasives, or sponges with abrasives to clean the membrane surface.
5. If cleaning agents are required, they must be cleaned with a neutral cleaning agent that is free of abrasives, strong solvents, and is not strong acid or alkaline.
6. After cleaning, rinse with clean water and wipe the surface of the film with a clean and soft cloth.
7. Except for matte film, other films can be treated like normal cars without the need for sealing or coating. It is recommended to regularly perform routine waxing care on the film surface, with a maintenance cycle of four times a year, but it is not recommended to polish the film surface.
8. Avoid using hard objects to scrape and avoid using items with adhesive to stick to the surface of the film.
9. In order to maintain the brightness of the film surface as new and extend its service life, please handle the following situations promptly:
 - 1) Wash the car promptly after long-distance high-speed driving, otherwise there will be a large number of insect bodies adhering to the film surface, making it difficult to clean;
 - 2) Do not park under trees for a long time, as there may be a large amount of bird droppings and shellac adhering to the membrane surface, exacerbating damage to the membrane structure;
 - 3) Do not park under the exhaust fan of the range hood for a long time, as there may be a large amount of oil stains on the film surface, making it difficult to clean;
 - 4) Do not park at the dripping point of the air conditioning outlet for a long time, otherwise corrosive air conditioning water will damage the membrane structure;
 - 5) Wash the car promptly after rain, otherwise the strong acidic substances in the rainwater will intensify the erosion of the film surface under sunlight.



Xiamen New Material Technology Co., LTD

Add.: Room 1201, No. 2555, Binhai West Avenue, XiKe Town, Tong 'an District, Xiamen, Fujian, China 361199

Website: kenteerwrap.com

E-mail: susie@kenteer.com

Tel.: +86-18159130125